

Security Door Stopper Alarm (2 pack)



Introduction

The SecurityMan DOORSTOPALM is a simple way to provide security to your home or business from unauthorized entries. This compact door stop alarm is very easy to install and does not require any drilling or running wires. Simply insert the 3x AAA batteries and your set. The DOORSTOPALM is equipped with a 120 decibel alarm which is loud enough to hear from anywhere in the house. It is padded on the bottom with non-skid rubber to keep a secure grip. It is pressure sensitive so that the alarm will trigger immediately when the door is opened.

Features

- 120dB Loud siren
- Battery powered; no wiring or complicated installation
- Small and portable
- Pressure activated.
- On/Off switch
- 1 year battery life
- Works with all hinged doors


Package Contents

- DOORSTOPALM (2pcs)
- AAA batteries (6pcs included)
- Security Warning stickers (2pcs)
- User's manual

Specifications

- Siren: 120dB
- Alarm length: 30 Seconds
- Power req: 3 AAA Batteries (included)
- On/Off Switch: Yes
- Material: ABS, Steel
- Dimensions (LxWxH): 6.25" x 1.75" x 1.5"
- Weight (Gross / Net): .60lbs (G) / .30lbs (N)

Product basics



Setup

1. Remove the battery cover.
2. Insert the 3 AAA batteries (included) as indicated by the polarity symbols (+ and -) and reattach the battery cover.
3. Move the on/off switch to the on position and place the DOORSTOPALM in front of the door.

NOTE: The DOORSTOPALM is pressure activated and the closer the unit is placed in front of the door the quicker it will trip.

Disclaimer: The DOORSTOPALM requires a minimum gap of 6/16 of an inch and no higher than 1 7/16 of an inch for the door to hit and trip it.



© Copyright 2018

This manual is furnished under license and may be used or copied only in accordance with the terms of such license. Except as permitted by such license, no part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, recording, or otherwise, including translation to another language or format, without the prior written permission of SecurityMan. The content of this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by SecurityMan. SecurityMan Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in this book.

FCC Information
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warranty
SecurityMan Inc. warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year or otherwise specified on the product packaging. This limited warranty shall commence from the date of purchase. SecurityMan products warranty is not transferable and is limited to the original purchaser. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, SecurityMan will repair or replace the product. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, normal wear and tear, or any condition other than what can be considered normal use.

If you encounter any difficulty in the operation of this product after reading the manual, please feel free to contact us. You can reach us by phone at 1-888-977-3777 from 8:30 AM to 5:30 PM Monday through Friday (Pacific Standard Time) or by email techsupport@securitymaninc.com. We will be happy to answer your questions and help you in any way we can.